

ANACONDA SEALTITE®

(LFNC-A) NON-METALLIC CONDUIT CUTTING AND NICKEL-PLATED BRASS TYPE A FITTING INSTALLATION

Cut non-metallic conduit (CNP) clean and square with a sharp shoe knife or a PVC cutter. Reduce frictional drag while cutting by applying a drop of liquid soap to "wet" the shoe knife. Do NOT use a saw or abrasion cutter to cut non-metallic conduit or burrs may be made on the conduit end.




Conduit Cutting Tips

- Make sure conduit is perpendicular, \perp , to the cutting blade.

Fitting Installation Tips

- Make sure rough edges are removed from inside and outside the conduit.
- Remove the clamping nut (A) and ferrule (C) from the fitting body (D).
- Put the clamping nut (A) and sealing ring (B) on the conduit.
- Fully tighten the ferrule (C) in the conduit.
- Tighten the fitting body (D) on the clamping nut (B) to UL/CSA torque.



NOTE: The clamping nut (B) is not shown fully tightened.