

# ANACONDA SEALTITE® NON-METALLIC CONDUIT CUTTING AND TYPE A FITTING INSTALLATION

Cut non-metallic conduit clean and square with a sharp shoe knife or a PVC cutter. Reduce frictional drag while cutting by applying a drop of liquid soap to “wet” the shoe knife. Do NOT use a saw or abrasion cutter to cut non-metallic conduit or burrs may be made on the conduit end.





## Conduit Cutting Tips

- Make sure conduit is perpendicular,  $\perp$ , to the cutting blade.



## Fitting Installation Tips

- Make sure rough edges are removed from inside and outside the conduit.
- Disassemble the fitting.
- Put the clamping nut (A) on the conduit.
- Fully tighten the ferrule (B) in the conduit using the hex shape in the fitting body (C).
- Tighten the fitting body (C) on the clamping nut (A) to UL/CSA torque.



NOTE: The clamping nut (A) is not shown fully tightened.